

Please read the manual carefully!


These grips must be installed professionally. Failure to do so, may endanger your health or life. Damage to the product or the bike may also occur. In case of doubt, ask a specialist workshop for support.

Only mount these grips on bicycles.

The grips may only be mounted together with the supplied clamps and screws. Other clamps or screws are not permitted.


Any kind of modification is not permitted and may endanger your safety. The warranty will be voided by improper use, including modification to this product or failure to comply with these instructions.

Please keep this manual for future reference.



1.

Ensure that the handlebar is suitable for external clamping and has a diameter of 22.2 mm.



2.

Check that there is a free and straight mounting area with a minimum length of 126 mm on the handlebar.

3.

Clean and degrease the handlebar in the assembly area with alcohol / isopropanol.




4.

Place the corresponding clamping piece on the corresponding grip. The screw hole on the clamping piece must always point downwards.



5.

Loosely turn the screw a few turns into the clamping piece. Make sure that there is a sufficient amount of thread locker on the screw.



8.

Rotate both handles to a comfortable position. Make sure that the handle provides sound support for the heel of hand. The wrist should not bend off.

6.

Slide the parts onto the handlebars, make sure that the grips are arranged correctly. A slight resistance is usual here.



7.

Push the handle onto the handlebar until you reach the limit stop.

9.

Ensure that no gap is visible between the clamping piece and the handle/grip.



10.

Tighten the screws with a torque of 3 Nm. The handles/grips must no longer be able to be twisted or pulled off, otherwise there is a risk of falling.